

CUBISCAN 125 CART ASSEMBLY

Complete the following steps to assemble a Cubiscan 125 custom cart.



1 > Remove the handles, wheels, nuts, bolts, lock washers, and flat washers from their packaging. You will need a 3/4" and 3/8" ratchet socket.



2 > Place the cart on the ground like shown above so that the wheels can be attached.



3 > Place the three wheels in the holes provided on the bottom of the cart, one in each corner.



4 > Attach the three wheels by using the flat washer, lock washer, and then nut. Tighten the nut for all three wheels using the 3/4" socket.

CUBISCAN 125 CART ASSEMBLY CONT.



5 > Once the wheels are secure, tip the cart so it is resting on the wheels.



6 > Attach the short handle on the long side of the cart using two of the hex bolts. Use the 3/8" socket to tighten the bolts as needed.



7 > Attach the two long handles using the remaining bolts. Each handle requires four bolts. Tighten the bolts using the 3/8" socket.



8 > You are finished.